



INSTRUKCJA OBSŁUGI - MANUAL



ROCKS®
STOP ŻELAZA Z PASJĄ

OK-08.0112
Belka do podwieszania silnika 500 kg
Engine support, 500 kg

www.rooks.pl



OK-08.0112

Belka do podwieszania silnika 500 kg

Engine support 500 kg

UWAGA!

1. Belka służy wyłącznie do podtrzymania silnika o wadze do 500 kg.
2. Utrzymuj łańcuchy w stanie wolnym od korozji
3. Nie przekraczaj dopuszczalnego obciążenia stojaka.
4. Upewnij się, czy w danym modelu samochodu można oprzeć belkę na błotnikach. Nie zaleca się tego w przypadku błotników plastikowych i aluminiowych.

UŻYWANIE:

1. Ustaw belkę nad silnikiem w rynnach błotnika.
2. Dostosuj szerokość podpórek do komory silnika.
3. Chwyć łańcuchem za elementy konstrukcyjne bloku silnika.
4. Napnij łańcuch śrubami uchwytów.
5. Delikatnie opuść silnik.

CAUTION!

1. The beam is only used to support the engine with a weight of up to 500 kg.
2. Keep the chains free from corrosion
3. Do not exceed the permissible load on the stand.
4. Make sure that you can rest the beam on the fenders in your car model. This is not recommended for plastic and aluminum fenders.

USER INSTRUCTION:

1. Place the beam above the engine in the mudguards.
2. Adjust the width of the supports to the engine compartment.
3. Grip the chain for the construction of the engine block.
4. Tension the chain with the bolts of the handles.
5. Gently lower the engine.